





LEXON[®]


LH95
STELI



Steli Dome



Steli Shade



Steli Bell

ENGLISH

IN THE BOX

1x Steli 1x USB Type-C charging cable 1x User manual

PRODUCT OVERVIEW

1. Touch area (Lighting function)
2. Lamp
3. BT Button (for lamp synchronisation)
4. Reset key
5. Receiver for wireless charging
6. LED indicator (battery & charging status)
7. USB Type-C charging port

FEATURES

- LED technology with 9 colors (warm white, cold white, blue, yellow, green, red, purple, light pink & light blue)
- Dimmable LED lights with memory system
- Synchronisable LED lamp (Bluetooth mesh network)
- Suitable for outdoor use (IPX4)
- Rechargeable via wireless charging or USB Type-C

CHARGING

We recommend you to fully charge the battery before using Steli for the first time. The initial full charge should take approximately 3 hours via USB charging and 7 hours via wireless charging.

LED information

Charge with USB cable	LED status (Red LED)
Charging	LED indicator remains ON
In use	LED indicator remains OFF
Fully charged	LED indicator remains OFF
Charge with Wireless charger	Lamp status
Charging	Lamp flashes green for 5 seconds when charging begins

Charge with USB cable

1. Plug the provided USB Type-C cable into the charging port of Steli.
2. Plug the USB end of the cable into any computer or any DC 5V power supply charger.

Charge with Wireless Charger

- Steli has a built-in wireless charging receiver. You can charge the battery by using a wireless charger.
1. Place Steli at the center of the wireless charger.
 2. Disconnect the device once the battery has been fully charged

OPERATING INSTRUCTIONS

Setting up one Steli lamp

- Touch the top of the lamp to turn it ON.
 - There are 9 colors options you can select by simply touching the top of the lamp.
 - To adjust brightness, touch the top area until you reached the desired brightness then release.
 - To turn OFF the light, wait 3 seconds after the color selection then touch again.
- The last color set will be remembered for next time.

Note: If you want to set Steli in cool and warm light mode only, quickly tap 3 times on the top area. To return to full set lighting mode, repeat the procedure.

Syncing several Steli lamps (Interconnection network)

Syncing Steli with one or multiple Steli lamps does not require any third-party software/device. To enjoy the multiple bulbs synchronization feature, follow below instructions:

1. Press and hold the BT button at the bottom of each lamp for 3 seconds to turn ON the communication module. The Blue LED will start flashing.
2. Select one of the lamps and press the BT button twice to initiate the multi-pairing procedure. Once procedure is complete, all lamps will be on the same color setting. The lamp used for connection is now identified a MASTER in the system, its LED will keep flashing while others are turned OFF

You can now interact from any lamp the change the color, adjust brightness or turn ON & OFF all lamps at once.

Important note: Bluetooth will automatically turn off after the lamp has been off for 60 minutes.

If you enable the Bluetooth® on one of your lamps to connect it to the network, but do not complete the pairing, the lamp's Bluetooth mode will turn off after 3 minutes automatically

Add one or more Steli lamps to the network

1. To add one or more Steli lamps to the network, simply to it (them) ON by pressing and holding the BT button on each unit for 3 seconds.
2. Press once on the pairing button of any lamp from the existing network (repeat the procedure with any new device).

Exclusive LOCK NETWORK feature

Steli is equipped with a unique locking system allowing only One lamp to control all others, preventing any change of color, brightness or even turn ON/OFF to be made from any other lamp in the network. The main lamp (MASTER) is the only one to control the network. All other lamps are becoming SLAVES.

To enable LOCK function, take the MASTER units and follow below instructions:

1. Press 5 times on the BT MASTER device button, it will send signal to ALL other lamps to LOCK.
2. In LOCK mode, only MASTER interact with other lamps. Its LED is double flashing every 3 seconds.
3. Network can be unlocked by quickly pressing 5 times on the BT button from the MASTER lamp

To change the MASTER device

1. Make sure the network is UNLOCKED
2. Quickly Press the BT button on any device for 10 times, this device will become the new MASTER device. You can now LOCK and UNLOCK the network from this new device.

Important note: In LOCKED/UNLOCKED network mode, it is strongly recommended to always keep the MASTER device in charge or fully charged to get the best experience and avoid loss of control of the entire network.

Other working operations:

- To turn OFF ALL the lamps when the network is locked, double tap on the top of the MASTER device. You'll need to tap on the MASTER again to turn all lamps back ON.
- To turn OFF only one lamp when the network is locked, long press on the BT button from more than 15 seconds until the lamp turns OFF. (This will remove the lamp from the network. Repeat the pairing procedure above to bring it back to the network)
- To reset the lamp, insert a thin object into the hole (4) under the lamp and press the key inside. A manual reset allows you to reboot your device and correct miscellaneous bugs (unrecognized device, unstable Bluetooth connection...).

LED Information

Operation mode	LED status (Blue LED)
Ready to pair	Blinking quickly
Master device	Blinking twice every 3 seconds
Locked devices	Off

SAFETY PRECAUTIONS

- IPX4 water resistant device, resistant to rain, splash, and spray water.
- Never immerse your device in water to avoid internal short circuit, overheating, fire, deformation or even explosion of the battery.
- Do not store your device in very hot or cold areas. It is recommended to use your device at room temperatures.
- Do not attempt to service, repair or disassemble the device yourself.
- Make sure to respect the technical specifications for charging and never use a power adapter delivering more voltage output than the one indicated to avoid any irreversible damage to the internal circuit (DC Input: 5V)
- Do not place the Steli case on the wireless charger when conductive materials, such as metal objects and magnets, are placed between the Steli case and the wireless charger. Use only certified wireless chargers.

PRODUCT SPECIFICATIONS

Material: Aluminium/ABS

Weight: 135 g / 0.29 lbs

Dimensions: Ø3.7 x 28.6-29.4 x Ø7.7 cm / Ø1.46 x 11.23-11.57 x Ø3.06"

Max lumen output: 120 lm

Color temperature:

Warm white: 2700K

Cold white: 6500K

Battery voltage: 3.7V

Charging time (wirelessly): approx. 5 hours

Operating temperature: 0°C - 45°C

Bluetooth® range: 10m

Frequency range: 2402M-2480MHZ

Input port: DC 5V

Wireless input: 5W

Battery type: Li-polymer

Battery capacity: 1500 mAh

Charging system: USB Type-C or Supports wireless charging

Charging time (USB Type-C): approx. 3 hours

Normal usage time: Up to 10h* (brightness at 75%)

International warranty: 1 year

*may vary based on product use, set light intensity and selected light color

FRANÇAIS

DANS LA BOÎTE

1x Steli

1x Câble de charge USB Type-C

1x Manuel d'utilisation

VUE D'ENSEMBLE

1. Surface tactile (fonction d'éclairage)
2. Lampe
3. Bouton Bluetooth (pour la synchronisation des lampes)
4. Bouton de réinitialisation
5. Récepteur pour la recharge sans fil
6. Indicateur LED (état de la batterie et de la charge)
7. Port de charge USB Type-C

FEATURES

- Technologie LED avec 9 couleurs (blanc chaud, blanc froid, bleu, jaune, vert, rouge, violet, rose clair et bleu clair)
- Lampe avec variateur d'intensité et système de mémorisation
- Lampe synchronisable (réseau maillé Bluetooth)
- Adaptée pour une utilisation en extérieur (IPX4)
- Rechargeable via la charge sans fil ou via le câble USB Type-C

MISE EN CHARGE

Nous vous recommandons de charger complètement la batterie avant d'utiliser Steli pour la première fois. La charge initiale complète dure environ 3 heures via la charge USB et 7 heures via la charge sans fil (par induction)

Informations sur l'indicateur LED

Mise en charge avec le câble USB	Statut de la LED (LED rouge)
Chargement en cours	Le voyant LED reste allumé
En cours d'utilisation	Le voyant LED reste éteint
Chargement complet	Le voyant LED reste éteint
Mise en charge avec le chargeur sans fil	État de la lampe
Chargement en cours	La lampe clignote en vert pendant 5 secondes lorsque le chargement commence

Mise en charge avec le câble USB

1. Branchez le câble USB Type-C fourni sur le port de charge du Steli.
2. Branchez l'autre extrémité USB du câble à n'importe quel ordinateur ou à n'importe quel chargeur à alimentation en courant continu 5V

Mise en charge avec le chargeur sans fil

Steli dispose d'un récepteur de charge sans fil intégré. Vous pouvez charger la batterie en utilisant un chargeur sans fil (par induction)

1. Placez le Steli au centre du chargeur sans fil.
2. Retirez l'appareil une fois que la batterie a été entièrement chargée.

INSTRUCTIONS D'UTILISATION

Utilisation d'une lampe Steli

- Appuyez une fois sur le haut de la lampe pour l'allumer.
- Il existe 9 options de couleurs que vous pouvez sélectionner en appuyant simplement sur le haut de la lampe.
- Pour régler la luminosité, touchez la partie supérieure de la lampe jusqu'à ce que vous atteigniez la luminosité souhaitée, puis relâchez.
- Pour éteindre la lampe, attendez 3 secondes après la sélection de la couleur puis appuyez à nouveau sur le haut de la lampe. La dernière couleur choisie restera en mémoire.

Remarque : si vous souhaitez régler le Steli en mode de lumière froide et chaude uniquement, appuyez rapidement 3 fois sur le haut de la lampe. Pour revenir au mode d'éclairage complet, répétez la procédure.

Synchronisation avec plusieurs lampes Steli (Réseau interconnecté)

La synchronisation de Steli avec une ou plusieurs lampes Steli ne nécessite aucun logiciel/dispositif tiers.

Pour profiter de la fonction de synchronisation de plusieurs ampoules, suivez les instructions ci-dessous :

1. Appuyez et maintenez enfoncé le bouton BT qui se trouve sous chaque lampe pendant 3 secondes pour allumer le module de communication. La LED bleue se met à clignoter.
 2. Sélectionnez une des lampes et appuyez deux fois sur le bouton BT pour lancer la procédure de connexion.
- Une fois la procédure terminée, toutes les lampes seront de la même couleur. La lampe utilisée pour lors de la connexion est maintenant identifiée comme MASTER dans le système, sa LED continuera à clignoter tandis que les autres seront éteintes.

Vous pouvez maintenant utiliser n'importe quelle lampe pour changer la couleur, régler la luminosité ou allumer et éteindre toutes les lampes en même temps.

Remarque importante : le Bluetooth s'éteint automatiquement après 60 minutes d'inactivité de la lampe.

Si vous activez le Bluetooth® sur l'une de vos lampes pour la connecter au réseau, mais que vous ne terminez pas la procédure, le mode Bluetooth de la lampe se désactivera automatiquement au bout de 3 minutes.

Ajouter une ou plusieurs lampes Steli au réseau

1. Pour ajouter une ou plusieurs lampes Steli au réseau, il suffit de les allumer en appuyant sur le bouton BT de chaque unité pendant 3 secondes.
2. Appuyez une fois sur le bouton de connexion de n'importe quelle lampe du réseau existant (répétez la procédure avec tout nouveau dispositif).

Fonction exclusive de VERROUILLAGE DU RÉSEAU

Steli est équipée d'un système de verrouillage unique permettant à une seule lampe de contrôler toutes les autres, empêchant tout changement de couleur, de luminosité ou même de mise en marche/arrêt à partir de toute autre lampe du réseau. La lampe principale (MASTER) est la seule à contrôler le réseau. Toutes les autres lampes deviennent des TÉMOINS.

Pour activer la fonction exclusive de VERROUILLAGE, prenez le MASTER et suivez les instructions ci-dessous :

1. Appuyez 5 fois sur le bouton BT du MASTER, il enverra un signal à TOUTES les autres lampes pour les verrouiller.
2. En mode LOCK, seul le MASTER interagit avec les autres lampes. Sa LED clignote deux fois toutes les 3 secondes.
3. Le réseau peut être déverrouillé en appuyant rapidement 5 fois sur le bouton BT de la lampe MASTER.

Pour changer le dispositif MASTER

1. Assurez-vous que le réseau est DÉVERROUILLÉ
2. Appuyez rapidement sur le bouton BT de n'importe quel appareil pendant 10 fois, cet appareil deviendra le nouvel appareil MASTER. Vous pouvez maintenant verrouiller et déverrouiller le réseau à partir de ce nouveau dispositif.

Remarque importante : en mode réseau VERROUILLÉ / DÉVERROUILLÉ, il est fortement recommandé de toujours garder l'appareil MASTER en charge ou complètement chargé pour obtenir une expérience optimale et éviter la perte de contrôle de l'ensemble du réseau.

Autres opérations de fonctionnement :

- Pour éteindre TOUTES les lampes lorsque le réseau est verrouillé, tapez deux fois sur le dessus de l'appareil MASTER. Vous devrez taper à nouveau sur le MASTER pour rallumer toutes les lampes.
- Pour éteindre une seule lampe lorsque le réseau est verrouillé, appuyez longuement sur le bouton BT pendant plus de 15 secondes jusqu'à ce que la lampe s'éteigne. (La lampe sera alors retirée du réseau. Répétez la procédure d'appairage ci-dessus pour la réintégrer au réseau).
- Pour réinitialiser la lampe, insérez un objet fin dans le trou (4) sous la lampe et appuyez sur le bouton à l'intérieur de ce trou. Une réinitialisation manuelle vous permet de redémarrer votre appareil et de corriger divers bugs (appareil non reconnu, connexion Bluetooth instable...).

Informations sur l'indicateur LED

Mode	Statut de la LED (LED bleue)
Prêt pour l'appariement	Clignotement rapide
Dispositif principal	Clignotement deux fois toutes les 3 secondes
Dispositifs verrouillés	Éteint

PRÉCAUTIONS DE SÉCURITÉ

- Appareil étanche IPX4, résistant à la pluie, aux éclaboussures et aux projections d'eau.
 - Ne plongez jamais votre appareil dans l'eau pour éviter tout court-circuit interne, toute surchauffe, tout incendie, toute déformation ou même toute explosion de la batterie.
 - Ne placez pas votre appareil dans des endroits très chauds ou très froids. Il est recommandé d'utiliser votre appareil à température ambiante.
 - N'essayez pas d'entretenir, de réparer ou de démonter l'appareil vous-même.
 - Veillez à respecter les spécifications techniques de charge et n'utilisez jamais un adaptateur électrique délivrant une tension de sortie supérieure à celle indiquée afin d'éviter tout dommage irréversible au circuit interne (Entrée: 5V).
 - Ne placez pas le boîtier Steli sur le chargeur sans fil lorsque des matériaux conducteurs, tels que des objets métalliques et des aimants, sont placés entre le boîtier Steli et le chargeur sans fil.
- Utilisez uniquement des chargeurs sans fil certifiés.

SPÉCIFICATIONS DU PRODUIT

Matériau : Aluminium/ABS

Poids : 135 g

Dimensions : Ø3.7 x 28.6-29.4 x Ø7.7 cm

Rendement lumineux max : 120 lm

Température de couleur :

Blanc chaud : 2700K

Blanc froid : 6500K

Tension de la batterie : 3.7V

Autonomie : Jusqu'à 10h* (luminosité à 75%)

Operating temperature: 0°C - 45°C

*varie en fonction de l'utilisation, de l'intensité lumineuse définie et de la couleur de lumière sélectionnée

Portée Bluetooth® : 10m

Gamme de fréquences : 2402M-2480MHZ

Port d'entrée : DC 5V

Entrée sans fil : 5W

Type de batterie : Li-polymère

Capacité de la batterie : 1500 mAh

Système de charge : USB Type-C ou Prise en charge de la charge sans fil

Charging time (USB Type-C): approx. 3 heures

Temps de charge (sans fil) : environ 5 heures

Garantie internationale : 1 an

EUROPEAN UNION CE DIRECTIVE

LEXON hereby declares that the device follows the essential requirements and other relevant provisions of the RED Directive 2014/53/EU.

The original EU declaration of conformity may be found at:
<https://www.lexon-design.com/assets/certifications-ce-steli.pdf>

RF Specification:

This device was tested for uncontrolled environment operations. To comply with RF exposure requirements, a minimum separation distance of 20 cm must be maintained between the user's body and the product.

LEXON déclare que cet appareil est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive RE Directives 2014/53/EU.

La déclaration de conformité originale de l'UE peut être consultée à l'adresse suivante : <https://www.lexon-design.com/assets/certifications-ce-steli.pdf>

Déclaration d'exposition RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

UK CONFORMITY ASSESSMENT

The object described above is in conformity with the essential requirements and other relevant provisions of the UK Radio Equipment Regulations 2017 (SI 2017/1206).

The original UK declaration of conformity may be found at:
<https://www.lexon-design.com/assets/certifications-ukca-steli.pdf>.

This device was tested for uncontrolled environment operations. To comply with RF exposure requirements, a minimum separation distance of 20cm must be maintained between the user's body and the product.

WPT:

Radiated H-Field: -34.32 dBuA/m(@10m)

TX/RX Frequency Range: 110-148 KHz

Bluetooth :

Transmitter power : 8.12dBm

TX/RX Frequency Range: 2400-2480MHz

DISPOSAL AND RECYCLING INFORMATION

After the implementation of the European Directive 2012/19/EU in the national legal system, the following applies: electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return electrical and electronic device at the end of their service lives to the public collecting points set up for this purpose or point of sale. Details to this are defined by the national law of the respective country. This symbol on the product, the instruction manual or the package indicates that a product is subject to these regulations. By recycling, reusing the materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.

USA - FCC STATEMENT

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation. Notice:

Any changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

RF exposure statements

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

CANADA COMPLIANCE STATEMENT

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

- 1) This device may not cause interference, and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Cet appareil contient des émetteurs / récepteurs exempts de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:

Cet appareil ne doit pas causer d'interférences.

Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil.

Déclaration d'exposition RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.



LEXON

125, Avenue des Champs-Élysées - 75008 Paris - FRANCE

All brands or product names are or may be trademarks or their respective owners.
Pictures and specifications are not contractual. Assembled in China.

[lexon-design.com](https://www.lexon-design.com) | [@lexondesign](https://www.lexon-design.com)